

DMX Values

12-Cell Personalities

12-Cell RGBAW FULL (160 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Red fine 1	000 ⇄ 255	0–100%
5	Green 1	000 ⇄ 255	0–100%
6	Green fine 1	000 ⇄ 255	0–100%
7	Blue 1	000 ⇄ 255	0–100%
8	Blue fine 1	000 ⇄ 255	0–100%
9	Amber 1	000 ⇄ 255	0–100%
10	Amber fine 1	000 ⇄ 255	0–100%
11	White 1	000 ⇄ 255	0–100%
12	White fine 1	000 ⇄ 255	0–100%
13	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
16	Red 2	000 ⇄ 255	0–100%
17	Red fine 2	000 ⇄ 255	0–100%
18	Green 2	000 ⇄ 255	0–100%
19	Green fine 2	000 ⇄ 255	0–100%
20	Blue 2	000 ⇄ 255	0–100%
21	Blue fine 2	000 ⇄ 255	0–100%
22	Amber 2	000 ⇄ 255	0–100%
23	Amber fine 2	000 ⇄ 255	0–100%
24	White 2	000 ⇄ 255	0–100%
25	White fine 2	000 ⇄ 255	0–100%
26	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
27	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
28	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
29	Red 3	000 ⇄ 255	0–100%
30	Red fine 3	000 ⇄ 255	0–100%
31	Green 3	000 ⇄ 255	0–100%
32	Green fine 3	000 ⇄ 255	0–100%
33	Blue 3	000 ⇄ 255	0–100%
34	Blue fine 3	000 ⇄ 255	0–100%
35	Amber 3	000 ⇄ 255	0–100%
36	Amber fine 3	000 ⇄ 255	0–100%
37	White 3	000 ⇄ 255	0–100%
38	White fine 3	000 ⇄ 255	0–100%
39	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
40	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
41	Strobe 3	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
42	Red 4	000 ⇔ 255	0–100%
43	Red fine 4	000 ⇔ 255	0–100%
44	Green 4	000 ⇔ 255	0–100%
45	Green fine 4	000 ⇔ 255	0–100%
46	Blue 4	000 ⇔ 255	0–100%
47	Blue fine 4	000 ⇔ 255	0–100%
48	Amber 4	000 ⇔ 255	0–100%
49	Amber fine 4	000 ⇔ 255	0–100%
50	White 4	000 ⇔ 255	0–100%
51	White fine 4	000 ⇔ 255	0–100%
52	Color macros 4	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
53	Color temperature 4	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
54	Strobe 4	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
55	Red 5	000 ⇔ 255	0–100%
56	Red fine 5	000 ⇔ 255	0–100%
57	Green 5	000 ⇔ 255	0–100%
58	Green fine 5	000 ⇔ 255	0–100%
59	Blue 5	000 ⇔ 255	0–100%
60	Blue fine 5	000 ⇔ 255	0–100%
61	Amber 5	000 ⇔ 255	0–100%
62	Amber fine 5	000 ⇔ 255	0–100%
63	White 5	000 ⇔ 255	0–100%
64	White fine 5	000 ⇔ 255	0–100%
65	Color macros 5	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
66	Color temperature 5	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
67	Strobe 5	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
68	Red 6	000 ⇔ 255	0–100%
69	Red fine 6	000 ⇔ 255	0–100%
70	Green 6	000 ⇔ 255	0–100%
71	Green fine 6	000 ⇔ 255	0–100%
72	Blue 6	000 ⇔ 255	0–100%
73	Blue fine 6	000 ⇔ 255	0–100%
74	Amber 6	000 ⇔ 255	0–100%
75	Amber fine 6	000 ⇔ 255	0–100%
76	White 6	000 ⇔ 255	0–100%
77	White fine 6	000 ⇔ 255	0–100%
78	Color macros 6	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
79	Color temperature 6	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
80	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
81	Red 7	000 ⇄ 255	0–100%
82	Red fine 7	000 ⇄ 255	0–100%
83	Green 7	000 ⇄ 255	0–100%
84	Green fine 7	000 ⇄ 255	0–100%
85	Blue 7	000 ⇄ 255	0–100%
86	Blue fine 7	000 ⇄ 255	0–100%
87	Amber 7	000 ⇄ 255	0–100%
88	Amber fine 7	000 ⇄ 255	0–100%
89	White 7	000 ⇄ 255	0–100%
90	White fine 7	000 ⇄ 255	0–100%
91	Color macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
92	Color temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
93	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
94	Red 8	000 ⇄ 255	0–100%
95	Red fine 8	000 ⇄ 255	0–100%
96	Green 8	000 ⇄ 255	0–100%
97	Green fine 8	000 ⇄ 255	0–100%
98	Blue 8	000 ⇄ 255	0–100%
99	Bluefine 8	000 ⇄ 255	0–100%
100	Amber 8	000 ⇄ 255	0–100%
101	Amber fine 8	000 ⇄ 255	0–100%
102	White 8	000 ⇄ 255	0–100%
103	White fine 8	000 ⇄ 255	0–100%
104	Color macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
105	Color temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
106	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
107	Red 9	000 ⇄ 255	0–100%
108	Red fine 9	000 ⇄ 255	0–100%
109	Green 9	000 ⇄ 255	0–100%
110	Green fine 9	000 ⇄ 255	0–100%
111	Blue 9	000 ⇄ 255	0–100%
112	Blue fine 9	000 ⇄ 255	0–100%
113	Amber 9	000 ⇄ 255	0–100%
114	Amber fine 9	000 ⇄ 255	0–100%
115	White 9	000 ⇄ 255	0–100%
116	White fine 9	000 ⇄ 255	0–100%
117	Color macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
118	Color temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
119	Strobe 9	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
120	Red 10	000 ⇔ 255	0–100%
121	Red fine 10	000 ⇔ 255	0–100%
122	Green 10	000 ⇔ 255	0–100%
123	Green fine 10	000 ⇔ 255	0–100%
124	Blue 10	000 ⇔ 255	0–100%
125	Blue fine 10	000 ⇔ 255	0–100%
126	Amber 10	000 ⇔ 255	0–100%
127	Amber fine 10	000 ⇔ 255	0–100%
128	White 10	000 ⇔ 255	0–100%
129	White fine 10	000 ⇔ 255	0–100%
130	Color macros 10	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
131	Color temperature 10	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
132	Strobe 10	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
133	Red 11	000 ⇔ 255	0–100%
134	Red fine 11	000 ⇔ 255	0–100%
135	Green 11	000 ⇔ 255	0–100%
136	Green fine 11	000 ⇔ 255	0–100%
137	Blue 11	000 ⇔ 255	0–100%
138	Blue fine 11	000 ⇔ 255	0–100%
139	Amber 11	000 ⇔ 255	0–100%
140	Amber fine 11	000 ⇔ 255	0–100%
141	White 11	000 ⇔ 255	0–100%
142	White fine 11	000 ⇔ 255	0–100%
143	Color macros 11	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
144	Color temperature 11	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
145	Strobe 11	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
146	Red 12	000 ⇔ 255	0–100%
147	Red fine 12	000 ⇔ 255	0–100%
148	Green 12	000 ⇔ 255	0–100%
149	Green fine 12	000 ⇔ 255	0–100%
150	Blue 12	000 ⇔ 255	0–100%
151	Blue fine 12	000 ⇔ 255	0–100%
152	Amber 12	000 ⇔ 255	0–100%
153	Amber fine 12	000 ⇔ 255	0–100%
154	White 12	000 ⇔ 255	0–100%
155	White fine 12	000 ⇔ 255	0–100%
156	Color macros 12	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
157	Color temperature 12	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values

EN

Channel	Function	Value	Percent/Setting
158	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
159	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
160	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

12-Cell RGBAW Fine (120 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Red fine 1	000 ⇄ 255	0–100%
3	Green 1	000 ⇄ 255	0–100%
4	Green fine 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Blue fine 1	000 ⇄ 255	0–100%
7	Amber 1	000 ⇄ 255	0–100%
8	Amber fine 1	000 ⇄ 255	0–100%
9	White 1	000 ⇄ 255	0–100%
10	White fine 1	000 ⇄ 255	0–100%
11	Red 2	000 ⇄ 255	0–100%
12	Red fine 2	000 ⇄ 255	0–100%
13	Green 2	000 ⇄ 255	0–100%
14	Green fine 2	000 ⇄ 255	0–100%
15	Blue 2	000 ⇄ 255	0–100%
16	Blue fine 2	000 ⇄ 255	0–100%
17	Amber 2	000 ⇄ 255	0–100%
18	Amber fine 2	000 ⇄ 255	0–100%
19	White 2	000 ⇄ 255	0–100%
20	White fine 2	000 ⇄ 255	0–100%
21	Red 3	000 ⇄ 255	0–100%
22	Red fine 3	000 ⇄ 255	0–100%
23	Green 3	000 ⇄ 255	0–100%
24	Green fine 3	000 ⇄ 255	0–100%
25	Blue 3	000 ⇄ 255	0–100%
26	Blue fine 3	000 ⇄ 255	0–100%
27	Amber 3	000 ⇄ 255	0–100%
28	Amber fine 3	000 ⇄ 255	0–100%
29	White 3	000 ⇄ 255	0–100%
30	White fine 3	000 ⇄ 255	0–100%
31	Red 4	000 ⇄ 255	0–100%
32	Red fine 4	000 ⇄ 255	0–100%
33	Green 4	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
34	Green fine 4	000 ⇄ 255	0–100%
35	Blue 4	000 ⇄ 255	0–100%
36	Blue fine 4	000 ⇄ 255	0–100%
37	Amber 4	000 ⇄ 255	0–100%
38	Amber fine 4	000 ⇄ 255	0–100%
39	White 4	000 ⇄ 255	0–100%
40	White fine 4	000 ⇄ 255	0–100%
41	Red 5	000 ⇄ 255	0–100%
42	Red fine 5	000 ⇄ 255	0–100%
43	Green 5	000 ⇄ 255	0–100%
44	Green fine 5	000 ⇄ 255	0–100%
45	Blue 5	000 ⇄ 255	0–100%
46	Blue fine 5	000 ⇄ 255	0–100%
47	Amber 5	000 ⇄ 255	0–100%
48	Amber fine 5	000 ⇄ 255	0–100%
49	White 5	000 ⇄ 255	0–100%
50	White fine 5	000 ⇄ 255	0–100%
51	Red 6	000 ⇄ 255	0–100%
52	Red fine 6	000 ⇄ 255	0–100%
53	Green 6	000 ⇄ 255	0–100%
54	Green fine 6	000 ⇄ 255	0–100%
55	Blue 6	000 ⇄ 255	0–100%
56	Blue fine 6	000 ⇄ 255	0–100%
57	Amber 6	000 ⇄ 255	0–100%
58	Amber fine 6	000 ⇄ 255	0–100%
59	White 6	000 ⇄ 255	0–100%
60	White fine 6	000 ⇄ 255	0–100%
61	Red 7	000 ⇄ 255	0–100%
62	Red fine 7	000 ⇄ 255	0–100%
63	Green 7	000 ⇄ 255	0–100%
64	Green fine 7	000 ⇄ 255	0–100%
65	Blue 7	000 ⇄ 255	0–100%
66	Blue fine 7	000 ⇄ 255	0–100%
67	Amber 7	000 ⇄ 255	0–100%
68	Amber fine 7	000 ⇄ 255	0–100%
69	White 7	000 ⇄ 255	0–100%
70	White fine 7	000 ⇄ 255	0–100%
71	Red 8	000 ⇄ 255	0–100%
72	Red fine 8	000 ⇄ 255	0–100%
73	Green 8	000 ⇄ 255	0–100%
74	Green fine 8	000 ⇄ 255	0–100%
75	Blue 8	000 ⇄ 255	0–100%
76	Blue fine 8	000 ⇄ 255	0–100%
77	Amber 8	000 ⇄ 255	0–100%
78	Amber fine 8	000 ⇄ 255	0–100%
79	White 8	000 ⇄ 255	0–100%
80	White fine 8	000 ⇄ 255	0–100%
81	Red 9	000 ⇄ 255	0–100%
82	Red fine 9	000 ⇄ 255	0–100%
83	Green 9	000 ⇄ 255	0–100%
84	Green fine 9	000 ⇄ 255	0–100%
85	Blue 9	000 ⇄ 255	0–100%
86	Blue fine 9	000 ⇄ 255	0–100%
87	Amber 9	000 ⇄ 255	0–100%
88	Amber fine 9	000 ⇄ 255	0–100%

EN

Channel	Function	Value	Percent/Setting
89	White 9	000 ⇄ 255	0–100%
90	White fine 9	000 ⇄ 255	0–100%
91	Red 10	000 ⇄ 255	0–100%
92	Red fine 10	000 ⇄ 255	0–100%
93	Green 10	000 ⇄ 255	0–100%
94	Green fine 10	000 ⇄ 255	0–100%
95	Blue 10	000 ⇄ 255	0–100%
96	Blue fine 10	000 ⇄ 255	0–100%
97	Amber 10	000 ⇄ 255	0–100%
98	Amber fine 10	000 ⇄ 255	0–100%
99	White 10	000 ⇄ 255	0–100%
100	White fine 10	000 ⇄ 255	0–100%
101	Red 11	000 ⇄ 255	0–100%
102	Red fine 11	000 ⇄ 255	0–100%
103	Green 11	000 ⇄ 255	0–100%
104	Green fine 11	000 ⇄ 255	0–100%
105	Blue 11	000 ⇄ 255	0–100%
106	Blue fine 11	000 ⇄ 255	0–100%
107	Amber 11	000 ⇄ 255	0–100%
108	Amber fine 11	000 ⇄ 255	0–100%
109	White 11	000 ⇄ 255	0–100%
110	White fine 11	000 ⇄ 255	0–100%
111	Red 12	000 ⇄ 255	0–100%
112	Red fine 12	000 ⇄ 255	0–100%
113	Green 12	000 ⇄ 255	0–100%
114	Green fine 12	000 ⇄ 255	0–100%
115	Blue 12	000 ⇄ 255	0–100%
116	Blue fine 12	000 ⇄ 255	0–100%
117	Amber 12	000 ⇄ 255	0–100%
118	Amber fine 12	000 ⇄ 255	0–100%
119	White 12	000 ⇄ 255	0–100%
120	White fine 12	000 ⇄ 255	0–100%

12-Cell RGBAW EXT (99 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	White 1	000 ⇄ 255	0–100%
8	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
11	Red 2	000 ⇄ 255	0–100%
12	Green 2	000 ⇄ 255	0–100%
13	Blue 2	000 ⇄ 255	0–100%
14	Amber 2	000 ⇄ 255	0–100%
15	White 2	000 ⇄ 255	0–100%
16	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
17	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
18	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
19	Red 3	000 ⇄ 255	0–100%
20	Green 3	000 ⇄ 255	0–100%
21	Blue 3	000 ⇄ 255	0–100%
22	Amber 3	000 ⇄ 255	0–100%
23	White 3	000 ⇄ 255	0–100%
24	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
25	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
26	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
27	Red 4	000 ⇄ 255	0–100%
28	Green 4	000 ⇄ 255	0–100%
29	Blue 4	000 ⇄ 255	0–100%
30	Amber 4	000 ⇄ 255	0–100%
31	White 4	000 ⇄ 255	0–100%
32	Color macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
33	Color temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
34	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

Channel	Function	Value	Percent/Setting
35	Red 5	000 ⇄ 255	0–100%
36	Green 5	000 ⇄ 255	0–100%
37	Blue 5	000 ⇄ 255	0–100%
38	Amber 5	000 ⇄ 255	0–100%
39	White 5	000 ⇄ 255	0–100%
40	Color macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
41	Color temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
42	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
43	Red 6	000 ⇄ 255	0–100%
44	Green 6	000 ⇄ 255	0–100%
45	Blue 6	000 ⇄ 255	0–100%
46	Amber 6	000 ⇄ 255	0–100%
47	White 6	000 ⇄ 255	0–100%
48	Color macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
49	Color temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
50	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
51	Red 7	000 ⇄ 255	0–100%
52	Green 7	000 ⇄ 255	0–100%
53	Blue 7	000 ⇄ 255	0–100%
54	Amber 7	000 ⇄ 255	0–100%
55	White 7	000 ⇄ 255	0–100%
56	Color macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
57	Color temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
58	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
59	Red 8	000 ⇄ 255	0–100%
60	Green 8	000 ⇄ 255	0–100%
61	Blue 8	000 ⇄ 255	0–100%
62	Amber 8	000 ⇄ 255	0–100%
63	White 8	000 ⇄ 255	0–100%
64	Color macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
65	Color temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
66	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
67	Red 9	000 ⇄ 255	0–100%
68	Green 9	000 ⇄ 255	0–100%
69	Blue 9	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
70	Amber 9	000 ⇄ 255	0–100%
71	White 9	000 ⇄ 255	0–100%
72	Color macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
73	Color temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
74	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
75	Red 10	000 ⇄ 255	0–100%
76	Green 10	000 ⇄ 255	0–100%
77	Blue 10	000 ⇄ 255	0–100%
78	Amber 10	000 ⇄ 255	0–100%
79	White 10	000 ⇄ 255	0–100%
80	Color macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
81	Color temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
82	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
83	Red 11	000 ⇄ 255	0–100%
84	Green 11	000 ⇄ 255	0–100%
85	Blue 11	000 ⇄ 255	0–100%
86	Amber 11	000 ⇄ 255	0–100%
87	White 11	000 ⇄ 255	0–100%
88	Color macros 11	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
89	Color temperature 11	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
90	Strobe 11	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
91	Red 12	000 ⇄ 255	0–100%
92	Green 12	000 ⇄ 255	0–100%
93	Blue 12	000 ⇄ 255	0–100%
94	Amber 12	000 ⇄ 255	0–100%
95	White 12	000 ⇄ 255	0–100%
96	Color macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
97	Color temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
98	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
99	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

12-Cell RGBA EXT (87 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
8	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
10	Red 2	000 ⇄ 255	0–100%
11	Green 2	000 ⇄ 255	0–100%
12	Blue 2	000 ⇄ 255	0–100%
13	Amber 2	000 ⇄ 255	0–100%
14	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
15	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
17	Red 3	000 ⇄ 255	0–100%
18	Green 3	000 ⇄ 255	0–100%
19	Blue 3	000 ⇄ 255	0–100%
20	Amber 3	000 ⇄ 255	0–100%
21	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
22	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
23	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
24	Red 4	000 ⇄ 255	0–100%
25	Green 4	000 ⇄ 255	0–100%
26	Blue 4	000 ⇄ 255	0–100%
27	Amber 4	000 ⇄ 255	0–100%
28	Color macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
29	Color temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
30	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
31	Red 5	000 ⇄ 255	0–100%
32	Green 5	000 ⇄ 255	0–100%
33	Blue 5	000 ⇄ 255	0–100%
34	Amber 5	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
35	Color macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
36	Color temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
37	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
38	Red 6	000 ⇄ 255	0–100%
39	Green 6	000 ⇄ 255	0–100%
40	Blue 6	000 ⇄ 255	0–100%
41	Amber 6	000 ⇄ 255	0–100%
42	Color macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
43	Color temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
44	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
45	Red 7	000 ⇄ 255	0–100%
46	Green 7	000 ⇄ 255	0–100%
47	Blue 7	000 ⇄ 255	0–100%
48	Amber 7	000 ⇄ 255	0–100%
49	Color macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
50	Color temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
51	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
52	Red 8	000 ⇄ 255	0–100%
53	Green 8	000 ⇄ 255	0–100%
54	Blue 8	000 ⇄ 255	0–100%
55	Amber 8	000 ⇄ 255	0–100%
56	Color macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
57	Color temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
58	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
59	Red 9	000 ⇄ 255	0–100%
60	Green 9	000 ⇄ 255	0–100%
61	Blue 9	000 ⇄ 255	0–100%
62	Amber 9	000 ⇄ 255	0–100%
63	Color macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
64	Color temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
65	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
66	Red 10	000 ⇄ 255	0–100%
67	Green 10	000 ⇄ 255	0–100%
68	Blue 10	000 ⇄ 255	0–100%
69	Amber 10	000 ⇄ 255	0–100%
70	Color macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
71	Color temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
72	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
73	Red 11	000 ⇄ 255	0–100%
74	Green 11	000 ⇄ 255	0–100%
75	Blue 11	000 ⇄ 255	0–100%
76	Amber 11	000 ⇄ 255	0–100%
77	Color macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
78	Color temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
79	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
80	Red 12	000 ⇄ 255	0–100%
81	Green 12	000 ⇄ 255	0–100%
82	Blue 12	000 ⇄ 255	0–100%
83	Amber 12	000 ⇄ 255	0–100%
84	Color macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
85	Color temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
86	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
87	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

12-Cell HSIC (85 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer 1	000 ⇄ 255	0–100%
2	Hue 1	000 ⇄ 255	0–100%
3	Hue fine 1	000 ⇄ 255	0–100%
4	Saturation 1	000 ⇄ 255	0–100%
5	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
6	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer 2	000 ⇄ 255	0–100%
9	Hue 2	000 ⇄ 255	0–100%
10	Hue fine 2	000 ⇄ 255	0–100%
11	Saturation 2	000 ⇄ 255	0–100%
12	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
13	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Dimmer 3	000 ⇄ 255	0–100%
16	Hue 3	000 ⇄ 255	0–100%
17	Hue fine 3	000 ⇄ 255	0–100%
18	Saturation 3	000 ⇄ 255	0–100%
19	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
20	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
21	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
22	Dimmer 4	000 ⇄ 255	0–100%
23	Hue 4	000 ⇄ 255	0–100%
24	Hue fine 4	000 ⇄ 255	0–100%
25	Saturation 4	000 ⇄ 255	0–100%
26	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
27	Color macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
28	Color temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
29	Dimmer 5	000 ⇄ 255	0–100%
30	Hue 5	000 ⇄ 255	0–100%
31	Hue fine 5	000 ⇄ 255	0–100%
32	Saturation 5	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
33	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
34	Color macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
35	Color temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
36	Dimmer 6	000 ⇄ 255	0–100%
37	Hue 6	000 ⇄ 255	0–100%
38	Hue fine 6	000 ⇄ 255	0–100%
39	Saturation 6	000 ⇄ 255	0–100%
40	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
41	Color macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
42	Color temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
43	Dimmer 7	000 ⇄ 255	0–100%
44	Hue 7	000 ⇄ 255	0–100%
45	Hue Fine 7	000 ⇄ 255	0–100%
46	Saturation 7	000 ⇄ 255	0–100%
47	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
48	Color macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
49	Color temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
50	Dimmer 8	000 ⇄ 255	0–100%
51	Hue 8	000 ⇄ 255	0–100%
52	Hue fine 8	000 ⇄ 255	0–100%
53	Saturation 8	000 ⇄ 255	0–100%
54	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
55	Color macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
56	Color temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
57	Dimmer 9	000 ⇄ 255	0–100%
58	Hue 9	000 ⇄ 255	0–100%
59	Hue fine 9	000 ⇄ 255	0–100%
60	Saturation 9	000 ⇄ 255	0–100%
61	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
62	Color macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values

Channel	Function	Value	Percent/Setting
63	Color temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
64	Dimmer 10	000 ⇄ 255	0–100%
65	Hue 10	000 ⇄ 255	0–100%
66	Hue fine 10	000 ⇄ 255	0–100%
67	Saturation 10	000 ⇄ 255	0–100%
68	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
69	Color macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
70	Color temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
71	Dimmer 11	000 ⇄ 255	0–100%
72	Hue 11	000 ⇄ 255	0–100%
73	Hue Fine 11	000 ⇄ 255	0–100%
74	Saturation 11	000 ⇄ 255	0–100%
75	Strobe 11	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
76	Color macros 11	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
77	Color temperature 11	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
78	Dimmer 12	000 ⇄ 255	0–100%
79	Hue 12	000 ⇄ 255	0–100%
80	Hue Fine 12	000 ⇄ 255	0–100%
81	Saturation 12	000 ⇄ 255	0–100%
82	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
83	Color macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
84	Color temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
85	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

12-Cell RGB EXT (75 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
9	Red 2	000 ⇄ 255	0–100%
10	Green 2	000 ⇄ 255	0–100%
11	Blue 2	000 ⇄ 255	0–100%
12	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
13	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
14	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
15	Red 3	000 ⇄ 255	0–100%
16	Green 3	000 ⇄ 255	0–100%
17	Blue 3	000 ⇄ 255	0–100%
18	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
19	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
20	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
21	Red 4	000 ⇄ 255	0–100%
22	Green 4	000 ⇄ 255	0–100%
23	Blue 4	000 ⇄ 255	0–100%
24	Color macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
25	Color temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
26	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
27	Red 5	000 ⇄ 255	0–100%
28	Green 5	000 ⇄ 255	0–100%
29	Blue 5	000 ⇄ 255	0–100%
30	Color macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
31	Color temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
32	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
33	Red 6	000 ⇄ 255	0–100%
34	Green 6	000 ⇄ 255	0–100%
35	Blue 6	000 ⇄ 255	0–100%
36	Color macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
37	Color temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
38	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
39	Red 7	000 ⇄ 255	0–100%
40	Green 7	000 ⇄ 255	0–100%
41	Blue 7	000 ⇄ 255	0–100%
42	Color macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
43	Color temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
44	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
45	Red 8	000 ⇄ 255	0–100%
46	Green 8	000 ⇄ 255	0–100%
47	Blue 8	000 ⇄ 255	0–100%
48	Color macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
49	Color temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
50	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
51	Red 9	000 ⇄ 255	0–100%
52	Green 9	000 ⇄ 255	0–100%
53	Blue 9	000 ⇄ 255	0–100%
54	Color macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
55	Color temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
56	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
57	Red 10	000 ⇄ 255	0–100%
58	Green 10	000 ⇄ 255	0–100%
59	Blue 10	000 ⇄ 255	0–100%
60	Color macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
61	Color temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
62	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
63	Red 11	000 ⇄ 255	0–100%
64	Green 11	000 ⇄ 255	0–100%
65	Blue 11	000 ⇄ 255	0–100%
66	Color macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
67	Color temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
68	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
69	Red 12	000 ⇄ 255	0–100%
70	Green 12	000 ⇄ 255	0–100%
71	Blue 12	000 ⇄ 255	0–100%
72	Color macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
73	Color temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
74	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
75	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

12-Cell RGBAW (60 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	White 1	000 ⇄ 255	0–100%
6	Red 2	000 ⇄ 255	0–100%
7	Green 2	000 ⇄ 255	0–100%
8	Blue 2	000 ⇄ 255	0–100%
9	Amber 2	000 ⇄ 255	0–100%
10	White 2	000 ⇄ 255	0–100%
11	Red 3	000 ⇄ 255	0–100%
12	Green 3	000 ⇄ 255	0–100%
13	Blue 3	000 ⇄ 255	0–100%
14	Amber 3	000 ⇄ 255	0–100%
15	White 3	000 ⇄ 255	0–100%
16	Red 4	000 ⇄ 255	0–100%
17	Green 4	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
18	Blue 4	000 ⇄ 255	0–100%
19	Amber 4	000 ⇄ 255	0–100%
20	White 4	000 ⇄ 255	0–100%
21	Red 5	000 ⇄ 255	0–100%
22	Green 5	000 ⇄ 255	0–100%
23	Blue 5	000 ⇄ 255	0–100%
24	Amber 5	000 ⇄ 255	0–100%
25	White 5	000 ⇄ 255	0–100%
26	Red 6	000 ⇄ 255	0–100%
27	Green 6	000 ⇄ 255	0–100%
28	Blue 6	000 ⇄ 255	0–100%
29	Amber 6	000 ⇄ 255	0–100%
30	White 6	000 ⇄ 255	0–100%
31	Red 7	000 ⇄ 255	0–100%
32	Green 7	000 ⇄ 255	0–100%
33	Blue 7	000 ⇄ 255	0–100%
34	Amber 7	000 ⇄ 255	0–100%
35	White 7	000 ⇄ 255	0–100%
36	Red 8	000 ⇄ 255	0–100%
37	Green 8	000 ⇄ 255	0–100%
38	Blue 8	000 ⇄ 255	0–100%
39	Amber 8	000 ⇄ 255	0–100%
40	White 8	000 ⇄ 255	0–100%
41	Red 9	000 ⇄ 255	0–100%
42	Green 9	000 ⇄ 255	0–100%
43	Blue 9	000 ⇄ 255	0–100%
44	Amber 9	000 ⇄ 255	0–100%
45	White 9	000 ⇄ 255	0–100%
46	Red 10	000 ⇄ 255	0–100%
47	Green 10	000 ⇄ 255	0–100%
48	Blue 10	000 ⇄ 255	0–100%
49	Amber 10	000 ⇄ 255	0–100%
50	White 10	000 ⇄ 255	0–100%
51	Red 11	000 ⇄ 255	0–100%
52	Green 11	000 ⇄ 255	0–100%
53	Blue 11	000 ⇄ 255	0–100%
54	Amber 11	000 ⇄ 255	0–100%
55	White 11	000 ⇄ 255	0–100%
56	Red 12	000 ⇄ 255	0–100%
57	Green 12	000 ⇄ 255	0–100%
58	Blue 12	000 ⇄ 255	0–100%
59	Amber 12	000 ⇄ 255	0–100%
60	White 12	000 ⇄ 255	0–100%

EN

12-Cell RGBA (48 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	Red 2	000 ⇄ 255	0–100%
6	Green 2	000 ⇄ 255	0–100%
7	Blue 2	000 ⇄ 255	0–100%
8	Amber 2	000 ⇄ 255	0–100%
9	Red 3	000 ⇄ 255	0–100%
10	Green 3	000 ⇄ 255	0–100%
11	Blue 3	000 ⇄ 255	0–100%
12	Amber 3	000 ⇄ 255	0–100%
13	Red 4	000 ⇄ 255	0–100%
14	Green 4	000 ⇄ 255	0–100%
15	Blue 4	000 ⇄ 255	0–100%
16	Amber 4	000 ⇄ 255	0–100%
17	Red 5	000 ⇄ 255	0–100%
18	Green 5	000 ⇄ 255	0–100%
19	Blue 5	000 ⇄ 255	0–100%
20	Amber 5	000 ⇄ 255	0–100%
21	Red 6	000 ⇄ 255	0–100%
22	Green 6	000 ⇄ 255	0–100%
23	Blue 6	000 ⇄ 255	0–100%
24	Amber 6	000 ⇄ 255	0–100%
25	Red 7	000 ⇄ 255	0–100%
26	Green 7	000 ⇄ 255	0–100%
27	Blue 7	000 ⇄ 255	0–100%
28	Amber 7	000 ⇄ 255	0–100%
29	Red 8	000 ⇄ 255	0–100%
30	Green 8	000 ⇄ 255	0–100%
31	Blue 8	000 ⇄ 255	0–100%
32	Amber 8	000 ⇄ 255	0–100%
33	Red 9	000 ⇄ 255	0–100%
34	Green 9	000 ⇄ 255	0–100%
35	Blue 9	000 ⇄ 255	0–100%
36	Amber 9	000 ⇄ 255	0–100%
37	Red 10	000 ⇄ 255	0–100%
38	Green 10	000 ⇄ 255	0–100%
39	Blue 10	000 ⇄ 255	0–100%
40	Amber 10	000 ⇄ 255	0–100%
41	Red 11	000 ⇄ 255	0–100%
42	Green 11	000 ⇄ 255	0–100%
43	Blue 11	000 ⇄ 255	0–100%
44	Amber 11	000 ⇄ 255	0–100%
45	Red 12	000 ⇄ 255	0–100%
46	Green 12	000 ⇄ 255	0–100%
47	Blue 12	000 ⇄ 255	0–100%
48	Amber 12	000 ⇄ 255	0–100%

12-Cell RGB (36 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Red 2	000 ⇄ 255	0–100%
5	Green 2	000 ⇄ 255	0–100%
6	Blue 2	000 ⇄ 255	0–100%
7	Red 3	000 ⇄ 255	0–100%
8	Green 3	000 ⇄ 255	0–100%
9	Blue 3	000 ⇄ 255	0–100%
10	Red 4	000 ⇄ 255	0–100%
11	Green 4	000 ⇄ 255	0–100%
12	Blue 4	000 ⇄ 255	0–100%
13	Red 5	000 ⇄ 255	0–100%
14	Green 5	000 ⇄ 255	0–100%
15	Blue 5	000 ⇄ 255	0–100%
16	Red 6	000 ⇄ 255	0–100%
17	Green 6	000 ⇄ 255	0–100%
18	Blue 6	000 ⇄ 255	0–100%
19	Red 7	000 ⇄ 255	0–100%
20	Green 7	000 ⇄ 255	0–100%
21	Blue 7	000 ⇄ 255	0–100%
22	Red 8	000 ⇄ 255	0–100%
23	Green 8	000 ⇄ 255	0–100%
24	Blue 8	000 ⇄ 255	0–100%
25	Red 9	000 ⇄ 255	0–100%
26	Green 9	000 ⇄ 255	0–100%
27	Blue 9	000 ⇄ 255	0–100%
28	Red 10	000 ⇄ 255	0–100%
29	Green 10	000 ⇄ 255	0–100%
30	Blue 10	000 ⇄ 255	0–100%
31	Red 11	000 ⇄ 255	0–100%
32	Green 11	000 ⇄ 255	0–100%
33	Blue 11	000 ⇄ 255	0–100%
34	Red 12	000 ⇄ 255	0–100%
35	Green 12	000 ⇄ 255	0–100%
36	Blue 12	000 ⇄ 255	0–100%

3-Cell Personalities

3-Cell RGBAW FULL (43 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Red fine 1	000 ⇄ 255	0–100%
5	Green 1	000 ⇄ 255	0–100%
6	Green fine 1	000 ⇄ 255	0–100%
7	Blue 1	000 ⇄ 255	0–100%
8	Blue fine 1	000 ⇄ 255	0–100%
9	Amber 1	000 ⇄ 255	0–100%
10	Amber fine 1	000 ⇄ 255	0–100%
11	White 1	000 ⇄ 255	0–100%
12	White fine 1	000 ⇄ 255	0–100%
13	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
16	Red 2	000 ⇄ 255	0–100%
17	Red fine 2	000 ⇄ 255	0–100%
18	Green 2	000 ⇄ 255	0–100%
19	Green fine 2	000 ⇄ 255	0–100%
20	Blue 2	000 ⇄ 255	0–100%
21	Blue fine 2	000 ⇄ 255	0–100%
22	Amber 2	000 ⇄ 255	0–100%
23	Amber fine 2	000 ⇄ 255	0–100%
24	White 2	000 ⇄ 255	0–100%
25	White fine 2	000 ⇄ 255	0–100%
26	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
27	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
28	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
29	Red 3	000 ⇄ 255	0–100%
30	Red fine 3	000 ⇄ 255	0–100%
31	Green 3	000 ⇄ 255	0–100%
32	Green fine 3	000 ⇄ 255	0–100%
33	Blue 3	000 ⇄ 255	0–100%
34	Blue fine 3	000 ⇄ 255	0–100%
35	Amber 3	000 ⇄ 255	0–100%
36	Amber fine 3	000 ⇄ 255	0–100%
37	White 3	000 ⇄ 255	0–100%
38	White fine 3	000 ⇄ 255	0–100%
39	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
40	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
41	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
42	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
43	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

3-Cell RGBAW Fine (30 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Red fine 1	000 ⇄ 255	0–100%
3	Green 1	000 ⇄ 255	0–100%
4	Green fine 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Blue fine 1	000 ⇄ 255	0–100%
7	Amber 1	000 ⇄ 255	0–100%
8	Amber fine 1	000 ⇄ 255	0–100%
9	White 1	000 ⇄ 255	0–100%
10	White fine 1	000 ⇄ 255	0–100%
11	Red 2	000 ⇄ 255	0–100%
12	Red fine 2	000 ⇄ 255	0–100%
13	Green 2	000 ⇄ 255	0–100%
14	Green fine 2	000 ⇄ 255	0–100%
15	Blue 2	000 ⇄ 255	0–100%
16	Blue fine 2	000 ⇄ 255	0–100%
17	Amber 2	000 ⇄ 255	0–100%
18	Amber fine 2	000 ⇄ 255	0–100%
19	White 2	000 ⇄ 255	0–100%
20	White fine 2	000 ⇄ 255	0–100%
21	Red 3	000 ⇄ 255	0–100%
22	Red fine 3	000 ⇄ 255	0–100%
23	Green 3	000 ⇄ 255	0–100%
24	Green fine 3	000 ⇄ 255	0–100%
25	Blue 3	000 ⇄ 255	0–100%
26	Blue fine 3	000 ⇄ 255	0–100%
27	Amber 3	000 ⇄ 255	0–100%
28	Amber fine 3	000 ⇄ 255	0–100%
29	White 3	000 ⇄ 255	0–100%
30	White fine 3	000 ⇄ 255	0–100%

3-Cell RGBAW EXT (27 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer fine	000 ⇔ 255	0–100%
3	Red 1	000 ⇔ 255	0–100%
4	Green 1	000 ⇔ 255	0–100%
5	Blue 1	000 ⇔ 255	0–100%
6	Amber 1	000 ⇔ 255	0–100%
7	White 1	000 ⇔ 255	0–100%
8	Color macros 1	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
9	Color temperature 1	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe 1	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
11	Red 2	000 ⇔ 255	0–100%
12	Green 2	000 ⇔ 255	0–100%
13	Blue 2	000 ⇔ 255	0–100%
14	Amber 2	000 ⇔ 255	0–100%
15	White 2	000 ⇔ 255	0–100%
16	Color macros 2	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
17	Color temperature 2	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
18	Strobe 2	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
19	Red 3	000 ⇔ 255	0–100%
20	Green 3	000 ⇔ 255	0–100%
21	Blue 3	000 ⇔ 255	0–100%
22	Amber 3	000 ⇔ 255	0–100%
23	White 3	000 ⇔ 255	0–100%
24	Color Macros 3	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
25	Color Temperature 3	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
26	Strobe 3	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
27	Strobe all	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast

3-Cell RGBA EXT (24 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
8	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
10	Red 2	000 ⇄ 255	0–100%
11	Green 2	000 ⇄ 255	0–100%
12	Blue 2	000 ⇄ 255	0–100%
13	Amber 2	000 ⇄ 255	0–100%
14	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
15	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
17	Red 3	000 ⇄ 255	0–100%
18	Green 3	000 ⇄ 255	0–100%
19	Blue 3	000 ⇄ 255	0–100%
20	Amber 3	000 ⇄ 255	0–100%
21	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
22	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
23	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
24	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

3-Cell HSIC (22 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer 1	000 ⇄ 255	0–100%
2	Hue 1	000 ⇄ 255	0–100%
3	Hue fine 1	000 ⇄ 255	0–100%
4	Saturation 1	000 ⇄ 255	0–100%
5	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
6	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer 2	000 ⇄ 255	0–100%
9	Hue 2	000 ⇄ 255	0–100%
10	Hue fine 2	000 ⇄ 255	0–100%
11	Saturation 2	000 ⇄ 255	0–100%
12	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
13	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Dimmer 3	000 ⇄ 255	0–100%
16	Hue 3	000 ⇄ 255	0–100%
17	Hue fine 3	000 ⇄ 255	0–100%
18	Saturation 3	000 ⇄ 255	0–100%
19	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
20	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
21	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
22	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

3-Cell RGB EXT (21 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
9	Red 2	000 ⇄ 255	0–100%
10	Green 2	000 ⇄ 255	0–100%
11	Blue 2	000 ⇄ 255	0–100%
12	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
13	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
14	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
15	Red 3	000 ⇄ 255	0–100%
16	Green 3	000 ⇄ 255	0–100%
17	Blue 3	000 ⇄ 255	0–100%
18	Color macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
19	Color temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
20	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
21	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

EN

3-Cell RGBAW (15 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	White 1	000 ⇄ 255	0–100%
6	Red 2	000 ⇄ 255	0–100%
7	Green 2	000 ⇄ 255	0–100%
8	Blue 2	000 ⇄ 255	0–100%
9	Amber 2	000 ⇄ 255	0–100%
10	White 2	000 ⇄ 255	0–100%
11	Red 3	000 ⇄ 255	0–100%
12	Green 3	000 ⇄ 255	0–100%
13	Blue 3	000 ⇄ 255	0–100%
14	Amber 3	000 ⇄ 255	0–100%
15	White 3	000 ⇄ 255	0–100%

3-Cell RGBA (12 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	Red 2	000 ⇄ 255	0–100%
6	Green 2	000 ⇄ 255	0–100%
7	Blue 2	000 ⇄ 255	0–100%
8	Amber 2	000 ⇄ 255	0–100%
9	Red 3	000 ⇄ 255	0–100%
10	Green 3	000 ⇄ 255	0–100%
11	Blue 3	000 ⇄ 255	0–100%
12	Amber 3	000 ⇄ 255	0–100%

3-Cell RGB (9 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Red 2	000 ⇄ 255	0–100%
5	Green 2	000 ⇄ 255	0–100%
6	Blue 2	000 ⇄ 255	0–100%
7	Red 3	000 ⇄ 255	0–100%
8	Green 3	000 ⇄ 255	0–100%
9	Blue 3	000 ⇄ 255	0–100%

2-Cell Personalities

2-Cell RGBAW FULL (30 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Red fine 1	000 ⇄ 255	0–100%
5	Green 1	000 ⇄ 255	0–100%
6	Green fine 1	000 ⇄ 255	0–100%
7	Blue 1	000 ⇄ 255	0–100%
8	Blue fine 1	000 ⇄ 255	0–100%
9	Amber 1	000 ⇄ 255	0–100%
10	Amber fine 1	000 ⇄ 255	0–100%
11	White 1	000 ⇄ 255	0–100%
12	White fine 1	000 ⇄ 255	0–100%
13	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
16	Red 2	000 ⇄ 255	0–100%
17	Red fine 2	000 ⇄ 255	0–100%
18	Green 2	000 ⇄ 255	0–100%
19	Green fine 2	000 ⇄ 255	0–100%
20	Blue 2	000 ⇄ 255	0–100%
21	Blue fine 2	000 ⇄ 255	0–100%
22	Amber 2	000 ⇄ 255	0–100%
23	Amber fine 2	000 ⇄ 255	0–100%
24	White 2	000 ⇄ 255	0–100%
25	White fine 2	000 ⇄ 255	0–100%
26	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
27	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
28	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
29	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
30	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

2-Cell RGBAW Fine (20 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Red fine 1	000 ⇄ 255	0–100%
3	Green 1	000 ⇄ 255	0–100%
4	Green fine 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Blue fine 1	000 ⇄ 255	0–100%
7	Amber 1	000 ⇄ 255	0–100%
8	Amber fine 1	000 ⇄ 255	0–100%
9	White 1	000 ⇄ 255	0–100%
10	White fine 1	000 ⇄ 255	0–100%
11	Red 2	000 ⇄ 255	0–100%
12	Red fine 2	000 ⇄ 255	0–100%
13	Green 2	000 ⇄ 255	0–100%
14	Green fine 2	000 ⇄ 255	0–100%
15	Blue 2	000 ⇄ 255	0–100%
16	Blue fine 2	000 ⇄ 255	0–100%
17	Amber 2	000 ⇄ 255	0–100%
18	Amber fine 2	000 ⇄ 255	0–100%
19	White 2	000 ⇄ 255	0–100%
20	White fine 2	000 ⇄ 255	0–100%

2-Cell RGBAW EXT (19 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	White 1	000 ⇄ 255	0–100%
8	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
11	Red 2	000 ⇄ 255	0–100%
12	Green 2	000 ⇄ 255	0–100%
13	Blue 2	000 ⇄ 255	0–100%
14	Amber 2	000 ⇄ 255	0–100%
15	White 2	000 ⇄ 255	0–100%
16	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
17	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
18	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

Channel	Function	Value	Percent/Setting
19	Strobe all	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast

2-Cell RGBA EXT (17 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer fine	000 ⇔ 255	0–100%
3	Red 1	000 ⇔ 255	0–100%
4	Green 1	000 ⇔ 255	0–100%
5	Blue 1	000 ⇔ 255	0–100%
6	Amber 1	000 ⇔ 255	0–100%
7	Color macros 1	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
8	Color temperature 1	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
10	Red 2	000 ⇔ 255	0–100%
11	Green 2	000 ⇔ 255	0–100%
12	Blue 2	000 ⇔ 255	0–100%
13	Amber 2	000 ⇔ 255	0–100%
14	Color macros 2	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
15	Color temperature 2	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
17	Strobe all	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast

2-Cell HSIC (15 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer 1	000 ⇄ 255	0–100%
2	Hue 1	000 ⇄ 255	0–100%
3	Hue fine 1	000 ⇄ 255	0–100%
4	Saturation 1	000 ⇄ 255	0–100%
5	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
6	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer 2	000 ⇄ 255	0–100%
9	Hue 2	000 ⇄ 255	0–100%
10	Hue fine 2	000 ⇄ 255	0–100%
11	Saturation 2	000 ⇄ 255	0–100%
12	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
13	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

2-Cell RGB EXT (15 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Color macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
9	Red 2	000 ⇄ 255	0–100%
10	Green 2	000 ⇄ 255	0–100%
11	Blue 2	000 ⇄ 255	0–100%
12	Color macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
13	Color temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
14	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
15	Strobe all	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

EN

2-Cell RGBAW (10 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	White 1	000 ⇄ 255	0–100%
6	Red 2	000 ⇄ 255	0–100%
7	Green 2	000 ⇄ 255	0–100%
8	Blue 2	000 ⇄ 255	0–100%
9	Amber 2	000 ⇄ 255	0–100%
10	White 2	000 ⇄ 255	0–100%

2-Cell RGBA (8 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	Red 2	000 ⇄ 255	0–100%
6	Green 2	000 ⇄ 255	0–100%
7	Blue 2	000 ⇄ 255	0–100%
8	Amber 2	000 ⇄ 255	0–100%

2-Cell RGB (6 channels)

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Red 2	000 ⇄ 255	0–100%
5	Green 2	000 ⇄ 255	0–100%
6	Blue 2	000 ⇄ 255	0–100%

1-Cell Personalities

1-Cell RGBAW FULL (16 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Red fine	000 ⇄ 255	0–100%
5	Green	000 ⇄ 255	0–100%
6	Green fine	000 ⇄ 255	0–100%
7	Blue	000 ⇄ 255	0–100%
8	Blue fine	000 ⇄ 255	0–100%
9	Amber	000 ⇄ 255	0–100%
10	Amber fine	000 ⇄ 255	0–100%
11	White	000 ⇄ 255	0–100%
12	White fine	000 ⇄ 255	0–100%
13	Color macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast
16	Dimmer speed	000 ⇄ 009	Preset dimmer speed from display menu
		010 ⇄ 029	Dimmer speed mode off
		030 ⇄ 069	Dimmer speed mode 1 (fastest)
		070 ⇄ 129	Dimmer speed mode 2
		130 ⇄ 189	Dimmer speed mode 3
		190 ⇄ 255	Dimmer speed mode 4 (slowest)

1-Cell - RGBAW Basic (13 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Green	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Amber	000 ⇄ 255	0–100%
7	White	000 ⇄ 255	0–100%
8	Color macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

Channel	Function	Value	Percent/Setting
11	Auto programs	000 ⇄ 040	No function
		041 ⇄ 050	Auto 1
		051 ⇄ 060	Auto 2
		061 ⇄ 070	Auto 3
		071 ⇄ 080	Auto 4
		081 ⇄ 090	Auto 5
		091 ⇄ 100	Auto 6
		101 ⇄ 110	Auto 7
		111 ⇄ 120	Auto 8
		121 ⇄ 130	Auto 9
		131 ⇄ 140	Auto 10
		141 ⇄ 150	Program 1
		151 ⇄ 160	Program 2
		161 ⇄ 170	Program 3
		171 ⇄ 180	Program 4
		181 ⇄ 190	Program 5
		191 ⇄ 200	Program 6
		201 ⇄ 210	Program 7
		211 ⇄ 220	Program 8
		221 ⇄ 230	Program 9
		231 ⇄ 240	Program 10
12	Auto speed	000 ⇄ 255	Auto program speed adjust
13	Auto delay	000 ⇄ 255	Auto program delay adjust

1-Cell RGBAW Fine (10 channels)

Channel	Function	Value	Percent/Setting
1	Red	000 ⇄ 255	0–100%
2	Red fine	000 ⇄ 255	0–100%
3	Green	000 ⇄ 255	0–100%
4	Green fine	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Blue fine	000 ⇄ 255	0–100%
7	Amber	000 ⇄ 255	0–100%
8	Amber fine	000 ⇄ 255	0–100%
9	White	000 ⇄ 255	0–100%
10	White fine	000 ⇄ 255	0–100%

1-Cell RGBAW EXT (10 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Green	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Amber	000 ⇄ 255	0–100%
7	White	000 ⇄ 255	0–100%
8	Color macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Strobe, slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lightning effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random strobe, slow to fast

1-Cell HSIC (9 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Hue	000 ⇔ 255	0–100%
3	Fine hue	000 ⇔ 255	0–100%
4	Saturation	000 ⇔ 255	0–100%
5	Strobe	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast
6	Color macros	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer speed	000 ⇔ 009	Preset dimmer speed from display menu
		010 ⇔ 029	Dimmer speed mode off
		030 ⇔ 069	Dimmer speed mode 1 (fastest)
		070 ⇔ 129	Dimmer speed mode 2
		130 ⇔ 189	Dimmer speed mode 3
		190 ⇔ 255	Dimmer speed mode 4 (slowest)
9	GN saturation	000 ⇔ 010	No function
		011 ⇔ 029	Full minus green
		030 ⇔ 069	-99% to -1%
		070 ⇔ 129	No function
		130 ⇔ 189	1% to 99%
		190 ⇔ 255	Full plus green

1-Cell RGBA EXT (9 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer fine	000 ⇔ 255	0–100%
3	Red	000 ⇔ 255	0–100%
4	Green	000 ⇔ 255	0–100%
5	Blue	000 ⇔ 255	0–100%
6	Amber	000 ⇔ 255	0–100%
7	Color macros	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
8	Color temperature	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast

EN

1-Cell RGB EXT (8 channels)

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇔ 255	0–100%
2	Dimmer fine	000 ⇔ 255	0–100%
3	Red	000 ⇔ 255	0–100%
4	Green	000 ⇔ 255	0–100%
5	Blue	000 ⇔ 255	0–100%
6	Color macros	000 ⇔ 255	Refer to the Color Macro Chart section for specific values
7	Color temperature	000 ⇔ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe	000 ⇔ 009	No function
		010 ⇔ 099	Strobe, slow to fast
		100 ⇔ 109	No function
		110 ⇔ 179	Lightning effect, slow to fast
		180 ⇔ 189	No function
		190 ⇔ 255	Random strobe, slow to fast

1-Cell RGBAW (5 channels)

Channel	Function	Value	Percent/Setting
1	Red	000 ⇔ 255	0–100%
2	Green	000 ⇔ 255	0–100%
3	Blue	000 ⇔ 255	0–100%
4	Amber	000 ⇔ 255	0–100%
5	White	000 ⇔ 255	0–100%

1-Cell RGBA (4 channels)

Channel	Function	Value	Percent/Setting
1	Red	000 ⇔ 255	0–100%
2	Green	000 ⇔ 255	0–100%
3	Blue	000 ⇔ 255	0–100%
4	Amber	000 ⇔ 255	0–100%

1-Cell RGB (3 channels)

Channel	Function	Value	Percent/Setting
1	Red	000 ⇔ 255	0–100%
2	Green	000 ⇔ 255	0–100%
3	Blue	000 ⇔ 255	0–100%